

Cisco MPP 6800 Series


Cisco IP Phone 6841 and 6851 Multiplatform Phones Buttons and Hardware



1	Handset and Handset light strip	Indicates whether you have an incoming call (flashing red) or a new voice message (steady red).
2	Programmable feature buttons and line buttons	 Access your phone lines, features, and call sessions. For more information, see Softkey, Line, and Feature Buttons .
3	Softkey buttons	 Access functions and services. For more information, see Softkey, Line, and Feature Buttons .
4	Navigation cluster	Navigation ring and Select  button. Scroll through menus, highlight items, and select the highlighted item.
5	Hold/Resume, Conference, and Transfer	Hold/Resume  Place an active call on hold and resume the held call. Conference  Create a conference call. Transfer  Transfer a call.
6	Speakerphone, Mute, and Headset	Speakerphone  Toggle the speakerphone on or off. When the speakerphone is on, the button is lit. Mute  Toggle the microphone on or off. When the microphone is muted, the button is lit. Headset  Toggle the headset on or off. When the headset is on, the button is lit.

Cisco MPP 6800 Phone Connections

Connect your phone to your LAN with an Ethernet cable to enable full functionality of your phone. If your Ethernet port is equipped with Power over Ethernet (PoE), you can power the phone through the LAN port. If you don't have PoE available, then you need to use a power adapter to power the phone. Do not extend the LAN Ethernet cable outside the building. For your phone to work, it must be connected to the IP telephony network.



1	Key Expansion Module port	5	Access port (10/100/1000 PC) connection (optional)
2	DC adapter port (optional)	6	Auxiliary port (optional)
3	Power adapter (optional)	7	Handset connection
4	Network port (10/100/1000 SW) connection; IEEE 802.3af power enabled	8	Analog headset connection (optional)

7	Contacts, Applications, and Messages	<p>Contacts  Access personal and corporate directories.</p> <p>Applications  Access call history, user preferences, phone settings, and phone model information.</p> <p>Messages  Autodial your voice messaging system.</p>
8	Volume button	 <p>Adjust the handset, headset, and speakerphone volume (off hook) and the ringer volume (on hook).</p>