

Cisco MPP 7800 Series

Cisco IP Phone 7800 Series Buttons and Features

[blocked URL](#)

1	Handset and Handset light strip	Indicates whether you have an incoming call (flashing red) or a new voice message (steady red).
2	Programmable feature buttons and line buttons	blocked URL Access your phone lines, features, and call sessions. For more information, see Softkey, Line, and Feature Button on page 13.
3	Softkey buttons	blocked URL Access functions and services. For more information, see Softkey, Line, and Feature Button on page 13.
4	Navigation cluster	Navigation ring and Select blocked URL button. Scroll through menus, highlight items, and select the highlighted item.
5	Hold/Resume, Conference, and Transfer	Hold/Resume blocked URL Place an active call on hold and resume the held call. Conference blocked URL Create a conference call. Transfer blocked URL Transfer a call.
6	Speakerphone, Mute, and Headset	Speakerphone blocked URL Toggle the speakerphone on or off. When the speakerphone is on, the button is lit. Mute blocked URL Toggle the microphone on or off. When the microphone is muted, the button is lit. Headset blocked URL Toggle the headset on or off. When the headset is on, the button is lit.
7	Contacts, Applications, and Messages	Contacts blocked URL Access personal and corporate directories. Applications blocked URL Access call history, user preferences, phone settings, and phone model information. Messages blocked URL Autodial your voice messaging system.
8	Volume button	blocked URL Adjust the handset, headset, and speakerphone volume (off hook) and the ringer volume(on hook).

Cisco IP Conference Phone 7832 Buttons and Features

[blocked URL](#)

The following table describes the buttons on the Cisco IP Conference Phone 7832.

1	Mute bar	blocked URL Toggle the microphone on or off. When the microphone is muted, the LED bar is lit red.
2	LED bar	Indicates call states: <ul style="list-style-type: none">• Green, solid—Active call• Green, flashing—Incoming call• Green, pulsing—Held call• Red, solid—Muted call
3	Softkey buttons	blocked URL Access functions and services.
4	Navigation bar and Select button	blocked URL Scroll through menus, highlight items, and select the highlighted item. When the phone is idle, press Up to access the recent calls list and press Down to access the favorites list.

Cisco IP Phone 7821 and 7841

Phone Connections

Connect your Cisco IP phone to your LAN with an Ethernet cable to enable full functionality of your Cisco IP phone. If your Ethernet port is equipped with Power over Ethernet (PoE), you can power the Cisco IP phone through the LAN port. Do not extend the LAN Ethernet cable outside the building. For your phone to work, it must be connected to the IP telephony network.

[blocked URL](#)

1	DC adaptor port (DC48V) (optional).	5	7821: Access port (10/100 PC) connection (optional). 7841: Access port (10/100/1000 PC) connection (optional).
2	AC-to-DC power supply (optional).	6	Auxiliary port (optional).
3	AC power wall plug (optional).	7	Handset connection.
4	Network port (10/100/1000 SW) connection. IEEE 802.3af power enabled.	8	Analog headset connection (optional).

5	Volume button	blocked URL Adjust the speakerphone volume (off hook) and the ringer volume (on hook). When you change the volume, the LED bar lights white to show the volume change.
---	---------------	---